
ALL SIZES IN MILLIMETRES


HomeFires 800 Corner Unit

Open freestanding fireplace for a corner: wood and anthracite, with flue and cowl

01 FRONT VIEW




02 SIDE VIEW




Front at the right.
A corner of the flue faces the front.

03 TOP VIEW



Back at the top. Front at the bottom.

04 FLOOR PLAN




The foot of the fireplace on the floor.

BRAAI CULTURE


ALL SIZES IN MILLIMETRES

HomeFires 800 Corner Unit

05 WITH THE FLUE (SMALLER SCALE)



06 FLUE PARTS (SMALLER SCALE)



PLANNING NOTES

The 760 height runs from the floor to the top of the unit, where the flue starts. The flue and the cowl go above it.
The 3.6 m is the length of the supplied pipes, not the height your roof needs. Plan the flue route with an installer.
The flue pipe is square, 180 by 180 on the outside.
Included: the basket grate, the grid, the ash drawer, the damper, the insulation material and the touch-up paint.
The listed heating volume is 120 m³.