
ALL SIZES IN MILLIMETRES


HomeFires Alpine 800 Wall Unit

Freestanding wall-unit fireplace: open, for wood or anthracite, with glass shields and a flue kit

01 FRONT VIEW




02 TOP VIEW




Back at the top. Ash drawer at the front.

03 FLUE OUTLET, FROM ABOVE



The flue connects here, on top of the hood.

04 SUPPLIED FLUE (SMALLER SCALE)




It comes with the fireplace, with one joining collar and an escutcheon plate.
The 3.6 m is a supplied length, not an installed height. For a taller roof, add extra flue pipe and collars on this page.
Ask us to confirm the cowl for your roof.

ALL SIZES IN MILLIMETRES


HomeFires Alpine 800 Wall Unit

05 HEARTH, FROM ABOVE (SMALLER SCALE)



White: the hearth. Front at the bottom.

06 CLEARANCES, FRONT VIEW (SMALLER SCALE)



PLANNING NOTES

These are product sizes, not a building opening. Your installer checks the actual unit and the safe clearances.
Keep 1,000 between the fire and furniture, curtains or anything else that can burn.
Use a hearth that reaches at least 350 in front of the fireplace and 200 at each side.
Keep the metal flue at least 200 from wood trusses. Your installer confirms the final layout for your room.
The heating volume is 120 m³. Burn wood or anthracite only: no coal and no briquettes.