
ALL SIZES IN MILLIMETRES


HomeFires R1201 Freestanding Fireplace with optional Stand

Closed combustion freestanding stove for wood and anthracite

01 FRONT VIEW, ON THE OPTIONAL STAND




02 SIDE VIEW, ON THE OPTIONAL STAND




Front at the right.

03 TOP VIEW



Front at the bottom.


04 CONSTRUCTIONAL HEARTH



BRAAI CULTURE


HomeFires R1201 Freestanding Fireplace with optional Stand

05 DISTANCES (SMALLER SCALE)



Dashed line: combustible material. Front at the bottom.

06 FIREBOX



PLANNING NOTES

These are product sizes. The heights run up to the top plate: the flue collar stands above it.
The stand is optional and is sold separately. Ask us for the stand depth.
Flue outlets: top and rear. Fit 6 mm rope with 125 mm pipes, or a 130–150 mm appliance adaptor with 150 mm pipes.
Ask us for the flue outlet size before you order pipes. The rear air inlet is not the rear flue outlet.
Keep the distances shown from combustible material. Your installer must confirm them for your stove.
Ask us for the distance to keep clear in front of the stove.
The hearth sizes are for a constructional hearth in an existing fireplace. They are not a cut-out size.
The listed heating volume is 280 m³.