
ALL SIZES IN MILLIMETRES


Jetmaster BLAZE with Log Box

Freestanding wood stove: closed slow combustion, a round body on a log box, with a wide glass window

01 FRONT VIEW




02 SIDE VIEW




Front at the right.
The 303.5 is the height of the log box front.

03 REAR VIEW



Seen from the back. The flue connects on top or at the rear.

04 TOP VIEW




Front at the bottom. The 163 is from the back of the body.

BRAAI CULTURE

ALL SIZES IN MILLIMETRES


Jetmaster BLAZE with Log Box

05 FIREBOX, CUT FRONT TO BACK (LARGER SCALE)



Front at the right, at the glass door. The log box is below.

06 FIREBOX, CUT FROM ABOVE (LARGER SCALE)



Front at the bottom.

PLANNING NOTES

These are product sizes. Ask us to confirm the safe clearances. Have your installer check the unit and the hearth.
Plan the stove, the hearth and the flue together.
Read the instruction manual on this page before you plan the installation.
Ask us to confirm the flue pipe size before you order. A standard flue section is 1,200 long.
Included: the log box, a grate, an ash pan and handle, a vermiculite plate set, two baffle plates, a flue blanking plate, a flue connector with a fireproof gasket, a fixings kit and a heat-resistant glove.
Flue pipes, a cowl and an escutcheon plate are chosen separately. Installation is not included.